



Hole Ht 11.75 x W 7.65" Frame Covers 0.25 to 0.5" Gap
 Choose a Location Near the Existing Push Chute.
 Check Hole Cut Will Not Remove Internal Bracing. Check that
 Opening Or Closing the DBA Door, Will Not Interfere or Hit
 Kit Includes Cutout Template

Place Door With Frame in Opening
Secure Frame with 10-24 Carrage Bolts
Thru Front into Wood Backing Blocks.

**Installation
Criteria**



Wood Blocks Support Door Frame to Table

PCB Mounted To Door Frame With 10-24 Bolt From Front

